

## **DOT&PF Instructions**

---

### **SWPPP Pre-Construction Site Visit (Form 25D-106)**

This form documents compliance with CGP and a requirement in the DOT&PF 641 specification. All projects meeting the criteria for CGP coverage are required to conduct a pre-construction site visit prior to the start of construction activities per spec. 641-2.01. Not every DOT&PF project requires having a pre-construction visit (it depends on the location and size). The form requires that the staff visiting the site consider phasing of the work, sequencing of the BMPs and which sediment controls must be installed prior to starting work. These considerations can be verified in the check-boxes on the form, and if the SWPPP needs to be changed, by creating an amendment as well. The SWPPP Preparer must sign the form.