
Republic Parking
6475 Airport Way
907.455.4571
Del.watkins@reimaginedparking.com

State of Alaska
Department of Transportation & Public Facilities
Fairbanks International Airport

TRANSIENT AIRCRAFT PARKING



- Transient Wheel and Ski parking available in Rows 10 -13 of paved parking ramp in front of the Air Traffic Control Tower (ATCT).
- Transient Float Spaces are available on the NE end of Float Pond, Spaces 160 – 163 (T1-T4).
- Transient AirPark Camping located NE of Ski Strip, accessed via Float Pond Road between Taxiway Delta and North Bypass Rd.